

**CERTIFIED FOR:** JOB NAME: CUSTOMER: CUSTOMER P.O.

SALES ORDER:

MODEL MP-2D 75-1640 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT AND **POSITIONING PIN** 2 INCH DEFLECTION

THE VMC GROUP DRAWING NO. The Power of Together Bloomingdale, NJ 07403

Houston, TX 77041

NONE SHEET: 1 OF 2

REVISION

120R-101713 | REV.: 7 REV. DESCRIPTION DATE BY READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING. 1. LOCATE ISOLATORS UNDER EQUIPMENT AFTER DETERMINING POSITIONS DESIGNATED IN THE VMC GROUP SUBMITTAL. SHEET 1. 2. ALL LIMIT BOLTS ARE FACTORY SET AND BONDED IN PLACE. THE SHIPPING NUT ON THE LIMIT BOLT MUST BE LOWERED UNTIL IT EQUIPMENT MOUNTING BRACKET TOUCHES THE BOLT HEAD. THE NUT WAS SHIPPED IN THE RAISED (BY OTHERS) POSITION. DO NOT ATTEMPT TO READJUST THE LIMIT BOLTS. FACTORY SETTING ASSURES UNIFORM BOLT LOADING IF UPLIFT OCCURS, AS IN THE CASE OF A COOLING TOWER BEING DRAINED. POSITIONING PIN 3. THE VMC GROUP RECOMMENDS BOLTING ALL ISOLATORS TO A REMOVABLE FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCESS OF ADJUSTING BOLT 20% OF EQUIPMENT OPERATING WEIGHT. THE ISOLATOR BASE PLATE MUST BE BOLTED. THE LOAD MUST BE CENTERED ON THE ISOLATOR TO AVOID ECCENTRIC LOADING OF TOP PLATE, WHICH WOULD TILT THE TOP PLATE OF THE ISOLATOR. THE TOP PLATE OF ADJUSTING NUT THE ISOLATOR MUST BE UNIFORMLY LOADED ACROSS ENTIRE LENGTH OF TOP PLATE OR THE EQUIPMENT MUST BE BLOCKED UNTIL LOAD IS TRANSFERRED TO THE ISOLATOR. THE VMC GROUP MUST BE ADVISED BEFORE THE ISOLATORS ARE RELEASED FOR STEEL SHIM PRODUCTION TO EVALUATE ANY VARIANCE TO THESE REQUIREMENTS. 3/8 GAP 4. WHEN THE APPLICATION IS OUTDOORS AND THE EQUIPMENT WILL BE SUBJECT TO HIGH WINDS. THE OWNER'S REPRESENTATIVE MUST EVALUATE ANCHOR TYPE AND SIZE TO EFFECTIVELY RESIST WIND FORCES. TYPE MP ISOLATORS ARE NOT SUITABLE FOR SEISMIC APPLICATIONS. USE VMC GROUP TYPE MS ISOLATORS TO ISOLATE EQUIPMENT THAT WILL BE SUBJECT TO SEISMIC FORCES. 5. ISOLATORS ARE SHIPPED TO THE JOB SITE WITH SHIMS BETWEEN SHIPPING NUT THE TOP PLATE AND HOUSING. THESE SHIMS MUST BE IN PLACE WHEN ISOLATOR IS POSITIONED UNDER EQUIPMENT. 6. THE ADJUSTMENT PROCESS CAN ONLY BEGIN AFTER FULL ·LIMIT-STOP BOLT OPERATING WEIGHT IS REACHED. THE ADJUSTMENTS CAN BE MADE BY STARTING AT ANY ISOLATOR AND TURNING THE ADJUSTING NUT CLOCKWISE TWO TURNS. PROCEED AROUND THE EQUIPMENT TO EACH ISOLATOR ADJUSTING EACH TWO TURNS TO COMPRESS THE SPRINGS UNIFORMLY. CONTINUE THIS ADJUSTING PROCESS UNTIL ONE ISOLATOR JUST RISES OFF THE SHIMS. STOP ADJUSTMENT ON THAT AND OTHER ISOLATORS AS THEY RISE OFF SHIMS APPROXIMATELY 1/32". WHEN ALL ISOLATORS HAVE RISEN ABOVE THE SHIMS, THE ADJUSTMENT PROCESS IS COMPLETE. 5/8 DIA HOLE REMOVE ALL SHIMS. (2 TYP BELOW 7. FURTHER ATTENTION TO THE INSTALLATION IS NOT NORMALLY LIMIT-STOP) REQUIRED. THE VMC GROUP SUGGESTS A SEMIANNUAL INSPECTION OF THE COMPONENTS FOR POSSIBLE CORROSION PROBLEMS. IF PROBLEMS ARE OBSERVED, CONSULT THE VMC

GROUP OR CORROSION CONTROL EXPERTS TO RECTIFY THE PROBLEM.

8. IF THE SPRING PACKAGE MUST BE REMOVED, CONTACT A FACTORY REPRESENTATIVE FOR DETAILED PROCEDURE ON SHEET.

OTHER MATERIALS, COMPOUNDS,	OR FINISHES WITH EQUAL OR SUPERIOR
PROPERTIES MAY BE SUBSTITUTE	D AS THEY BECOME AVAILABLE.

CERTIFIED FOR:	
JOB NAME:	
CUSTOMER:	
CUSTOMER P.O.:	
SALES ORDER:	

MODEL MP-2D 75-1640 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT AND **POSITIONING PIN** 2 INCH DEFLECTION

THE VMC GROUP	
The Power of Together	
Bloomingdale, NJ 07403	
Houston, TX 77041	

NONE SHEET:

2 OF 2

DRAWING NO.:

REVISION