

PROPRIETARY: EXCEPT AS OTHERWISE AGREED IN WRITING, THE INFORMATION AND DESIGN DISCLOSED HEREIN ARE THE PROPERTY OF THE VMC GROUP AND MUST NOT BE COPIED OR DISTRIBUTED OUTSIDE THE VMC GROUP EXCEPT TO AUTHORIZED PERSONS WITH A GENUINE NEED TO KNOW WHO BY THE USE HEREOF ACKNOWLEDGE THE VMC GROUP'S OWNERSHIP AND AGREE TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.

120R-101758 REV.: 6		REV.	DESCRIPTION	DATE	BY
READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING	<u>.</u>				
 LOCATE ISOLATORS UNDER EQUIPMENT AFTER DETERMINI POSITIONS DESIGNATED IN THE THE VMC GROUP SUBMITTA SHEET 1. ALL LIMIT BOLTS ARE FACTORY SET AND BONDED IN PLACE SHIPPING NUT ON THE LIMIT BOLT MUST BE LOWERED UNTI TOUCHES THE BOLT HEAD. THE NUT WAS SHIPPED IN THE I POSITION. DO NOT ATTEMPT TO READJUST THE LIMIT BOLT FACTORY SETTING ASSURES UNIFORM BOLT LOADING IF UF OCCURS, AS IN THE CASE OF A COOLING TOWER BEING DR 3. THE VMC GROUP RECOMMENDS BOLTING ALL ISOLATORS T FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCI 20% OF EQUIPMENT OPERATING WEIGHT, THE ISOLATORS IN FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCI 20% OF EQUIPMENT OPERATING WEIGHT, THE ISOLATOR BA PLATE MUST BE BOLTED. THE LOAD MUST BE CENTERED O ISOLATOR TO AVOID ECCENTRIC LOADING OF TOP PLATE, W WOULD TILT THE TOP PLATE OF THE ISOLATOR. THE TWC MUST BE BOLTED. THE LOAD MUST BE CENTERED O ISOLATOR TO AVOID ECCENTRIC LOADING OF TOP PLATE, W WOULD TILT THE TOP PLATE OR THE EQUIPMENT MUST BE BLOC UNTIL LOAD IS TRANSFERRED TO THE ISOLATOR. THE VMC MUST BE ADVISED BEFORE THE ISOLATORS ARE RELEASED PRODUCTION TO EVALUATE ANY VARIANCE TO THESE REQUIREMENTS. WHEN THE APPLICATION IS OUTDORS AND THE EQUIPMENT BE SUBJECT TO HIGH WINDS, THE OWNER'S REPRESENTATI MUST EVALUATE ANCHOR TYPE AND SIZE TO FFFECTIVELY WIND FORCES. TYPE MT ISOLATORS ARE NOT SUITABLE FO SEISMIC APPLICATIONS. USE VMC GROUP TYPES MS ISOLA TO ISOLATC EQUIPMENT THAT WILL BE SUBJECT TO SEISM FORCES. ISOLATORS ARE SHIPPED TO THE JOB SITE WITH SHIMS BET THE TOP PLATE AND HOUSING. THESE SHIMS MUST BE IN P WHEN ISOLATOR IS POSITIONED UNDER EQUIPMENT. THE ADJUSTMENT PROCESS CAN ONLY BEGIN AFTER FULL OPERATING WEIGHT IS REACHED. THE ADJUSTMENTS CAN MADE BY STARTING AT ANY ISOLATOR AND TURNING THE ADJUSTING NUT CLOCKWISE TWO TURNS. PROCEED AROU EQUIPMENT TO EACH ISOLATOR ADJUSTING EACH TWO TUP COMPRESS THE SPRINGS UNIFORMLY. CONTINUE THIS AD. OPERATING VEIGHT IS REACHED. THE ADJUSTMENT ON THAT ADJUSTMENT ON THAT AND OTHER ISOL	L, THE LIT RAISED S. TLIFT ANRED. OA SS OF SE NTHE HICH			VABLE SHIM NG BOL STOP BO	OLT OR SUPERIOR
CERTIFIED FOR:	MODEL MT-3R 5515-8320 LBS.		SCALE : NONE		
JOB NAME:	SPRING ISOLATORS WITH		SHEET:	1.01 1.01 1.01 1.01 1.01	
CUSTOMER :	INTERNAL ADJUSTMENT AND				, S . 7111
CUSTOMER P.O.:	ELASTOMERIC PAD-COVERED TOP PI	ATE	THE VMC GROUP The Power of Together	1	REVISION
SALES ORDER:	3 INCH DEFLECTION		Bloomingdale, NJ 07403 Houston, TX 77041		

PROPRIETARY: EXCEPT AS OTHERWISE AGREED IN WRITING, THE INFORMATION AND DESIGN DISCLOSED HEREIN ARE THE PROPERTY OF THE VMC GROUP AND MUST NOT BE COPIED OR DISTRIBUTED OUTSIDE THE VMC GROUP EXCEPT TO AUTHORIZED PERSONS WITH A GENUINE NEED TO KNOW WHO BY THE USE HEREOF ACKNOWLEDGE THE VMC GROUP'S OWNERSHIP AND AGREE TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.