120R-101799 REV.: 8		REV.	DESCRIPTION		DATE BY		
25 25 24 1/8		TYPE M2	E-5D SPRING I	SOLATORS WITH	INTERNAL ADJ	USTMENT	
			MAX LOAD	DEFLECTION	SPRING RATE	SPRING	
		MODEL	(LBS)	(IN)	(LB/IN)	COLOR CO	
		M2E-5D-5400	5400	4.63	1167	RED	
9		M2E-5D-5960	5960	4.47	1333	GREEN	
	5 3/4	M2E-5D-7670	7670	4.60	1667	LT IVORY	
		M2E-5D-9100N1	9100	4.63	1966	RED/BLACK	
/	3 1/4	M2E-5D-9530N ¹	9530	4.47	2134	GREEN/BLAC	Ж
		M2E-5D-11350N ¹	11350	4.60	2466	LT IVORY/BL/	ACK
		NOTES:				1	
EQUIPMENT SUPPORT BEAM (BY OT		1. TWO NESTED SPRI	NGS YIELD THIS LC	AD. THE COLOR COL	DE IS FOR OUTER SPI	RING/ INNER SPRIN	lG.
(NOT SHOWN IN OTHER VIEWS SHOWN IN OTHER VIEWS FOR		5/8 DIA EQUIPMENT STU (NUT AND WASHER, IF R					
FOR CLARITY) 之 (2 TYP) (2 TYP)		· · · · ·	. ,				
			SHIM (4 TYP) /E AFTER				
			ADJUSTMENT)				
			N FAR SIDE NOT				
			FOR CLARIT				
					0	_	
16 7/8			TOP (4 TYP)) 3	5	7	
FREE AND OPERATING	SPRING						
HEIGHT	- 1/4 RIBBED						
	PAD						
	3/4 DIA HOLE						
	(4 TYP)				6	(8)	
			(2) 4	0	\odot	
_ 	- 3 1/ 4						
NOTEO				ISOLATO	OR SELECTION	١S	
NOTES: 1. ALL DIMENSIONS ARE IN INCHES, INTERPRET PER ANSI Y14.			LOC 1:		LOC 2:		
2. UNLESS OTHERWISE NOTED, DIMENSIONS FOR STYLE APPLY TO			LOC 3:		LOC 4:		
 FINISH: HOUSINGS- POWDER COAT, SPRINGS- POWDER COAT, HA REFER TO SHEET 2 OF 2 FOR INSTALLATION INSTRUCTIONS. 	ARDWARE- ZINC ELECTROPLATE.		LOC 5: LOC 7:		LOC 6: LOC 8:		
5. INNER SPRING (WHEN USED) NOT SHOWN.			CUSTOMER I	EQP'T. TAG:	100 8.		
 ALL SPRINGS ARE DESIGNED WITH 50% OVER TRAVEL. SPRING PACKAGE MAY BE REMOVED WITH SHIMS IN PLACE. CON 				ERIAL SHOWN IS I	-OR (1) SET		
REMOVAL INSTRUCTIONS.							
<u>/8.</u> DIMENSIONS APPLY TO BOTH TOP BOLT DOWN AND BASE PLATE / 9. RATED DEFLECTIONS ARE WITHIN 25% OF NOMINAL, HIGHER DEFL					TERIALS, COMPOUNDS, OR		
	ECTIONS ARE ALLOWED IF THET MEET S	BRECIFICATIONS.		PROPERTIE	ES MAY BE SUBSTITUTED A		ABLE.
CERTIFIED FOR:					NON	F	_
JOB NAME: MODEL M2E-5D 5		5400-11350 LI	BS.			- <u>M</u> en	
	SPRING IS	OLATORS			SHEET:		SEWH
CUSTOMER :	WITH INTERNAL						
CUSTOMER P.O.:				HE VMC GRO		I	REVISION
	5 INCH DEF	-LECTION		The Power of Togeth Bloomingdale, NJ 07	ner 403		
SALES ORDER:				Houston, TX 7704			

PROPRIETARY: EXCEPT AS OTHERWISE AGREED IN WRITING, THE INFORMATION AND DESIGN DISCLOSED HEREIN ARE THE PROPERTY OF THE VMC GROUP AND MUST NOT BE COPIED OR DISTRIBUTED OUTSIDE THE VMC GROUP EXCEPT TO AUTHORIZED PERSONS WITH A GENUINE NEED TO KNOW WHO BY THE USE HEREOF ACKNOWLEDGE THE VMC GROUP'S OWNERSHIP AND AGREE TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.

R=101799 REV.: 8			DESCRIPTION	DATE	BY
 READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING. LOCATE ISOLATORS UNDER EQUIPMENT AFTER DETERMINING POSITIONS DESIGNATED IN THE VMC GROUP SUBMITTAL, SHEET 1. ALL LIMIT BOLTS ARE FACTORY SET AND BONDED IN PLACE. THE SHIPPING NUT ON THE LIMIT BOLT MUST BE LOWERED UNTIL IT TOUCHES THE BOLT HEAD. THE NUT WAS SHIPPED IN THE RAISED POSITION. DO NOT ATTEMPT TO READJUST THE LIMIT BOLTS. FACTORY SETTING ASSURES UNIFORM BOLT LOADING IF UPLIFT OCCURS, AS IN THE CASE OF A COOLING TOWER BEING DRAINED. THE VMC GROUP RECOMMENDS BOLTING ALL ISOLATORS TO A FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCESS OF 20% OF EQUIPMENT OPERATING WEIGHT, THE ISOLATOR BASE PLATE MUST BE BOLTED. STYLE "A" TOP PLATE MUST BE USED WITH A WIDE FLANGE BEAM BOLTED TO TOP PLATE MUST BE USED WITH A WIDE FLANGE BEAM BOLTED TO TOP PLATE AS SHOWN ON SUBMITTAL DRAWING. WHEN THE APPLICATION IS OUTDOORS AND THE EQUIPMENT WILL BE SUBJECT TO HIGH WINDS, THE OWNERS' REPRESENTATIVE MUST EVALUATE ANCHOR TYPE AND SIZE TO EFFECTIVELY RESIST WIND FORCES. TYPE ME ISOLATORS ARE NOT SUITABLE FOR SEISMIC APPLICATIONS. USE WIC GROUP TYPE MS ISOLATORS TO ISOLATE EQUIPMENT THAT WILL BE SUBJECT TO SEISMIC FORCES. ISOLATORS ARE SHIPPED TO THE JOB SITE WITH SHIMS BETWEEN THE TOP PLATE AND HOUSING. THESE SHIMS MUST BE IN PLACE WHEN ISOLATOR IS POSITIONED UNDER EQUIPMENT. THE ADJUSTMENT PROCESS CAN ONLY BEGIN AFTER FULL OPERATING WEIGHT IS REACHED. THE ADJUSTING NUT CLOCKWISE TWO TURNS. PROCEED AROUND THE EQUIPMENT TO EACH ISOLATOR ADJUSTING FACH TWO TURNS TO COMPRESS THE SPRINGS UNIFORMELY. CONTINUE THIS SAJUSTING PROCESS IS UNTL ONE ISOLATOR JUST RISES OFF THE SHIMS. STOP ADJUSTMENT ON THAT AND OTHER ISOLATORS AS THEY PRING VALISING FACH TWO TURNS TO COMPRESS IS COMPLETE. REMOVE ALL SHIMS. FURTHER ATTENTION TO THE INSTALLATION IS NOT NORMALLY REQUIRED. THE VMC GROUP SUGGESTS A SEMIANNUAL INSPECTION OF THE COMPONENTS FOR POSSIBLE CORROSION PROBLEMS. IF PROBLEMS ARE	REMOVABLE ADJUSTING BOLT		NUT AND WASHER		ERIC ER UT BOLT
JOB NAME:	MODEL M2E-5D 5400-11350 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT 5 INCH DEFLECTION	B	The Power of Together Hoomingdale, NJ 07403 Houston, TX 77041	- W.en	REVISION

PROPRIETARY: EXCEPT AS OTHERWISE AGREED IN WRITING, THE INFORMATION AND DESIGN DISCLOSED HEREIN ARE THE PROPERTY OF THE VMC GROUP AND MUST NOT BE COPIED OR DISTRIBUTED OUTSIDE THE VMC GROUP EXCEPT TO AUTHORIZED PERSONS WITH A GENUINE NEED TO KNOW WHO BY THE USE HEREOF ACKNOWLEDGE THE VMC GROUP'S OWNERSHIP AND AGREE TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.