

PROPRIETARY: EXCEPT AS OTHERWISE AGREED IN WRITING, THE INFORMATION AND DESIGN DISCLOSED HEREIN ARE THE PROPERTY OF THE VMC GROUP AND MUST NOT BE COPIED OR DISTRIBUTED OUTSIDE THE VMC GROUP EXCEPT TO AUTHORIZED PERSONS WITH A GENUINE NEED TO KNOW WHO BY THE USE HEREOF ACKNOWLEDGE THE VMC GROUP'S OWNERSHIP AND AGREE TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.

120R-101798 REV.: 6		REV.	DESCRIPTION	DATE	BY
READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNI	IG.				
 LOCATE ISOLATORS UNDER EQUIPMENT AFTER DETERMININ POSITIONS DESIGNATED IN THE VMC GROUP SUBMITTAL, SI- ALL LIMIT BOLTS ARE FACTORY SET AND BONDED IN PLACE. SHIPPING NUT ON THE LIMIT BOLT MUST BE LOWERED UNTIL TOUCHES THE BOLT HEAD. THE NUT WAS SHIPPED IN THE F POSITION. DO NOT ATTEMPT TO READJUST THE LIMIT BOLT. FACTORY SETTING ASSURES UNIFORM BOLT LOADING IF UP OCCURS, AS IN THE CASE OF A COOLING TOWER BEING DRA 3. THE VMC GROUP RECOMMENDS BOLTING ALL ISOLATORS T FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCE 20% OF EQUIPMENT OPERATING WEIGHT, THE ISOLATOR BA PLATE MUST BE BOLTED. THE LOAD MUST BE CENTERED OI ISOLATOR TO AVOID ECCENTRIC LOADING OF TOP PLATE, W WOULD TILT THE TOP PLATE OF THE ISOLATOR. THE TOP PL THE ISOLATOR MUST BE UNIFORMLY LOADED ACROSS ENTI- LENGTH OF TOP PLATE OR THE ISOLATOR. THE VMC MUST BE ADVISED BEFORE THE ISOLATORS ARE RELEASED PRODUCTION TO EVALUATE ANY VARIANCE TO THESE REQUIREMENTS. WHEN THE APPLICATION IS OUTDOORS AND THE EQUIPMEN BE SUBJECT TO HIGH WINDS, THE OWNER'S REPRESENTATT MUST EVALUATE ANCHOR TYPE AND SIZE TO EFFECTIVELY I WIND FORCES. TYPE MZT ISOLATORS ARE NOT SUITABLE F SEISMIC APPLICATIONS. USE VMC GROUP TYPES MS ISOLA TO ISOLATTE EQUIPMENT THAT WILL BE SUBJECT TO SEISMI FORCES. ISOLATORS ARE SHIPPED TO THE JOB SITE WITH SHIMS BET THE TOP PLATE AND HOUSING. THESE SHIMS MUST BE IN P WHEN ISOLATOR IS POSITIONED UNDER EQUIPMENT. THE ADJUSTMENT PROCESS CAN ONLY BEGIN AFTER FULL OPERATING WEIGHT IS REACHED. THE AJUJSTMENTS CAN MADE BY STARTING AT ANY ISOLATOR AND TURNING THE ADJUSTMENT TO CEXS CAN ONLY BEGIN AFTER FULL OPERATING WEIGHT IS REACHED. THE AJUSTMENTS CAN MADE BY STARTING AT AND OTHER ISOLATORS AS THEY RUS ADJUSTMENT ON THAT AND OTHER ISOLATORS AS THEY RUS THE SHIMS APPROXIMATELY 1/32". WHEN ALL ISOLATORS H RISEN ABOVE THE SPINIS UNIFORMLY. CONTINUE THIS ADJ PROCESS UNTIL ONE HOLLATOR, ADJUSTING EACH TWO TUP COMPLESS. THE SPRING PACKAGE MUST BE REMOVED, CONSULT THE V GROUP OR CORROSION CONTROL EXPERTS TO R	EET 1. THE IT AASED S. LIFT INED. DA SS OF SE IT THE HICH ATE OF RE ED GROUP FOR T WILL /E RESIST OR TORS C WEEN ACE BE ND THE INS TO JSTING STOP E OFF AVE LY ON WC			EL SHIM HIPPING N MIT-STOF 4 DIA HOL (4 TY)	P BOLT LE P)
CERTIFIED FOR:	MODEL M2T-5C 500-4600 LBS.		NONE		
JOB NAME:	SPRING ISOLATORS WITH		SHEET:		
CUSTOMER :	INTERNAL ADJUSTMENT AND				semi
CUSTOMER P.O.:	ELASTOMERIC PAD-COVERED TOP P	LATE	THE VMC GROUP DRAWING NO.: The Power of Together		REVISION
SALES ORDER:	5 INCH DEFLECTION		Bloomingdale, NJ 07403 Houston, TX 77041		

PROPRIETARY: EXCEPT AS OTHERWISE AGREED IN WRITING, THE INFORMATION AND DESIGN DISCLOSED HEREIN ARE THE PROPERTY OF THE VMC GROUP AND MUST NOT BE COPIED OR DISTRIBUTED OUTSIDE THE VMC GROUP EXCEPT TO AUTHORIZED PERSONS WITH A GENUINE NEED TO KNOW WHO BY THE USE HEREOF ACKNOWLEDGE THE VMC GROUP'S OWNERSHIP AND AGREE TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE.