

SALES ORDER:

3 INCH DEFLECTION

THE POWER OF TOGETHER**
Bloomingdale, NJ 07403

Houston, TX 77041

000 404740 10040 140/07/001		1 ,	20. /	DECODIDEION	l DATE	BY	_
20R-101719 REV.:8 10/03/22 READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING.			REV.	DESCRIPTION	DATE	БТ	_
1. LOCATE ISOLATORS UNDER EQUIPMENT AFTER DETERMINING POSITIONS DESIGNATED IN THE VMC GROUP SUBMITTAL, SHEET 1. 2. ALL LIMIT BOLTS ARE FACTORY SET AND BONDED IN PLACE. THE SHIPPING NUT ON THE LIMIT BOLT MUST BE LOWERED UNTIL IT TOUCHES THE BOLT HEAD. THE NUT WAS SHIPPED IN THE RAISED POSITION. DO NOT ATTEMPT TO READJUST THE LIMIT BOLTS. FACTORY SETTING ASSURES UNIFORM BOLT LOADING IF UPLIFT OCCURS, AS IN THE CASE OF A COOLING TOWER BEING DRAINED. 3. THE VMC GROUP RECOMMENDS BOLTING ALL ISOLATORS TO A FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCESS OF 20% OF EQUIPMENT OPERATING WEIGHT, THE ISOLATOR BASE PLATE MUST BE BOLTED. STYLE "A" TOP PLATE MUST BE USED WITH A WIDE FLANGE BEAM BOLTED TO TOP PLATE AS SHOWN ON SUBMITTAL DRAWING. 4. WHEN THE APPLICATION IS OUTDOORS AND THE EQUIPMENT WILL BE SUBJECT TO HIGH WINDS, THE OWNER'S REPRESENTATIVE MUST EVALUATE ANCHOR TYPE AND SIZE TO EFFECTIVELY RESIST WIND FORCES. TYPE ME ISOLATORS ARE RESTRICTED TO LOW SEISMIC AND WIND APPLICATIONS, STEEL ATTACHMENT ONLY. USE VMC GROUP TYPE MS ISOLATORS TO ISOLATE EQUIPMENT THAT WILL BE SUBJECT TO SEISMIC AND WIND FORCES WITH CONCRETE ATTACHMENT. 5. ISOLATORS ARE SHIPPED TO THE JOB SITE WITH SHIMS BETWEEN THE TOP PLATE AND HOUSING. THESE SHIMS MUST BE IN PLACE WHEN ISOLATOR IS POSITIONED UNDER EQUIPMENT. 6. THE ADJUSTMENT PROCESS CAN ONLY BEGIN AFTER FULL OPERATING WEIGHT IS REACHED. THE ADJUSTMENTS CAN BE MADE BY STARTING AT ANY ISOLATOR AND TURNING THE ADJUSTING NUT CLOCKWISE TWO TURNS. PROCEED AROUND THE EQUIPMENT TO EACH ISOLATOR ADJUSTING EACH TWO TURNS TO COMPRESS THE SPRINGS UNIFORMLY. CONTINUE THIS ADJUSTING PROCESS INTIL ONE ISOLATOR JUST RISES OFF THE SHIMS. STOP ADJUSTMENT ON THAT AND OTHER ISOLATORS AS THEY RISE OFF SHIMS APPROXIMATELY 1/32". WHEN ALL ISOLATORS HAVE RISEN ABOVE THE SHIMS, THE ADJUSTMENT PROCESS IS COMPLETE. REMOVE ALL SHIMS. 7. FURTHER ATTENTION TO THE INSTALLATION IS NOT NORMALLY REQUIRED. THE VMC GROUP SUGGESTS A SEMIANNUAL	REMOVABLE ADJUSTING BOLT —	SUPP	=:==:=	AM, BY OTHERS ADJUSTING NUT	REMOV STEEL SHIPPING LIMIT-STO	SHIM S NUT OP BOLT HOLE BELOW	Г
ADJUSTMENT PROCESS IS COMPLETE. REMOVE ALL SHIMS. 7. FURTHER ATTENTION TO THE INSTALLATION IS NOT NORMALLY		<u> </u>			LIIVII I -O	, 01)	

EXPERTS TO RECTIFY THE PROBLEM. 8. IF THE SPRING PACKAGE MUST BE REMOVED, CONTACT A FACTORY REPRESENTATIVE FOR SPRING REMOVAL INSTRUCTIONS.

OTHE	R MATERIALS, COM	POUNDS, OR FINIS	SHES WITH EQUAL	OR SUPERI
PROP	ERTIES MAY BE SUI	BSTITUTED AS THE	EY BECOME AVAIL	ABLE.



CERTIFIED FOR: JOB NAME: _

CUSTOMER: _

CUSTOMER P.O.: _

SALES ORDER:

MODEL ME-3C 75-1165 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT 3 INCH DEFLECTION



NONE SHEET:

DRAWING NO.:

2 OF 2

REVISION

THE POWER OF TOGETHER"