


CABLE SIZE	DIMENSION (IN.)			MAX FORCE
	А	С	F	(LBS.)
1/8"	2	1-5/8"	5-1/4"	430
3/16"	2	1-7/8"	5-3/4"	1053
1/4"	2	2-3/8"	6-3/4"	1850
5/16"	2	2-5/8"	7-3/8"	2575

INSTALLATION INSTRUCTIONS

- 1.) CABLE RESTRAINTS ARE INSTALLED AFTER EQUIPMENT, PIPE OR DUCT IS IN FINAL OPERATING POSITION. ATTACHMENT IS TO BE MADE TO RESTRAINED OBJECT AND SUPPORTING STRUCTURE AS SHOWN ELSEWHERE IN SUBMITTAL DETAILS.
- 2.) LEAVE CABLE ON SPOOL DURING INSTALLATION.
- 3.) MAKE UP STRUCTURE END OF CABLE BY LOOPING THROUGH BRACKET (FIG.1). ADD CABLE CLIPS AND TIGHTEN CLIPS.
- 4.) MAKE UP EQUIPMENT/PIPE/DUCT END BY PULLING CABLE HAND TIGHT THEN GIVE SLACK BY BACKING OUT 1/8". DO NOT LIFT ANY DEAD WEIGHT.
- 5.) INSTALL CLIPS, CUT CABLE FROM SPOOL.
- 6.) ADJUSTMENT OF CABLES MAY BE NECESSARY DUE TO UNANTICIPATED CHANGES IN OPERATING CONDITIONS.



OTHER MATERIALS, COMPOUNDS, OR FINISHES WITH EQUAL OR SUPERIOR PROPERTIES MAY BE SUBSTITUTED AS THEY BECOME AVAILABLE.

CERTIFIED FOR:			SCALE:	
JOB NAME:	MODEL SEISMIC CABLE		NONE	Membe,
	CONSTRUCTION FOR		SHEET:	···· ·VISCM A
CUSTOMER :	NON-ISOLATED PIPE, DUCT,			
CUSTOMER P.O.:	AND EQUIPMENT	THE VMC GROUP The Power of Together	DRAWING NO.:	REVISION
SALES ORDER:	AND EQUITIVIENT	Bloomingdale, NJ 07403 Houston, TX 77041		